
WARING PRO®

PROFESSIONAL POPCORN MAKER



WPM SERIES

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

IMPORTANT SAFEGUARDS

When using any electrical appliance, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR POPCORN MACHINE.

- 2. UNPLUG MAIN POWER CORD FROM OUTLET WHILE NOT IN USE AND BEFORE CLEANING.
- 3. Do not touch hot surfaces. Always use handles or knobs to operate.
- 4. To avoid any risk of electrical shock, do not immerse cord or plug into water or other liquids.
- 5. This appliance should not be used by or near children or individuals with certain disabilities.
- 6. Allow hot parts to cool down before maneuvering and cleaning.
- 7. Do not operate the appliance with damaged cord or plug, or after the appliance malfunctions or has been damaged in any matter. Send the unit to the nearest authorized service center for examination, repair or adjustment. (ONLY technicians should open up the unit.)
- 8. The use of any accessories or attachments not recommended by the manufacturer may cause injury.
- 9. Do not pop the kernels in a dry kettle (without oil).
- 10. Do not immerse popping kettle into water.
- 11. Kettle surface is **HOT** and should **NOT** be touched during popping or just after use.
- 12. Unplug, allow to cool, clean and cover the unit and store in a dry and safe place if not being used for a long time.
- 13. Do not let power cord hang over edge of table or counter or touch any hot surfaces.
- 14. Do not place the unit on or near a hot gas or electric burner or in a heated oven.
- 15. Extreme caution must be used when moving the appliance containing hot oil or other hot liquids.
- 16. Turn ALL switches to OFF position before disconnecting plug from the wall power supply outlet.

- 17. Not recommended for outdoor use.
- 18. Do not use appliance for other than intended use.
- 19. To avoid overheating, always add oil and then kernels before operating.
- 20. Extreme caution must be used when unloading popcorn. Always place the unit on a countertop so that residual hot oil or water running out will not cause burns.
- 21. KEEP OUT OF REACH OF CHILDREN.
- 22. DO NOT CLEAN USING ANY ABRASIVE MATERIAL.
- 23. NEVER FORCE ANY PARTS OR BRACKETS INTO POSITION.
- 24. CAUTION: Burns can result from misuse of this product. Read popping instructions for proper operating procedure.
- 25. No parts are intended for the dishwasher.
- 26. A popper that is plugged into an outlet should not be left unattended.
- 27. Do not operate your appliance in an appliance garage or under a wall cabinet. When storing in an appliance garage, always unplug the unit from the electrical outlet. Not doing so could create a risk of fire, especially if the appliance touches the walls of the garage or the door touches the unit as it closes.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

POWER CORD INSTRUCTION

This appliance is for 120 volts only and should not be used with a converter.


- A short power supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- 2. Longer, detachable power supply cords or extension cords may be used if care is exercised in their use.

- 3. If a long, detachable power supply cord or extension cord is used:
 - a) The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
 - b) If the appliance is of the grounded type, the extension cord should be a grounding 3-wire cord.
 - c) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

PARTS 000 7

- 1. Housing
- Kettle, Lid and Stirrer
- Door (removable)
- Tray (removable)
- 5. Light (not shown)
- 6. Measuring Spoon and Cup

ASSEMBLY PROCEDURE








FIGURE 1

Place door on hinges.

FIGURE 2

Hook the kettle onto the hanger of the main unit.








FIGURE 3

Insert tray.

FIGURE 4

Finally, insert the internal kettle plug into the socket on the inner top of the popcorn maker housing.

POPPING INSTRUCTIONS

- 1. Follow assembly procedure.
- 2. Make sure the popcorn maker is unplugged before you do any of the following:
 - Before using the unit, please check carefully to be sure voltage (120V-60 Hz) is suitable to your home.
 - Clean the internal surface of the kettle with warm sudsy water; rinse well and dry with a clean cloth. Wipe down inner and outer housing with damp cloth.
 - Insert the internal plug into the socket (see figure 4, previous page).
- 3. Main unit has a 2-function switch as follows:
 - POP to turn heater, stirrer and light on
 - OFF to turn power off
- 4. Plug the power cord into an electrical outlet.
- 5. Before pouring oil or popcorn, lift lid up using the lid tab. Turn the switch to the POP position. The stirrer will begin to rotate in the kettle. Let the stainless steel kettle preheat about 2 to 3 minutes. Add oil (1 tablespoon of vegetable, corn, peanut, or safflower oil). Immediately add 1/3 cup (70 grams) cup of corn kernels (Note: 1-tablespoon measure and 1/3 cup [70 grams] measuring cup included) and close lid to the kettle.

Caution: Lid might be hot – it is recommended to use an oven mitt.

- 6. Popcorn starts popping out through the lid after about 2 minutes. Yields up to 8 cups (1.89 liters) per batch in less than 3 minutes.
- 7. When unit is finished popping you will no longer hear the corn popping immediately turn switch to the OFF position and rotate the knob of the kettle down to release any remaining popcorn in the popper. This will also stop the remaining popcorn from cooking any further and avoid possible burning.
- 8. Keep POP switch off if the unit is not continuously in use.
- 9. Remove plug from power supply if the unit is not being used.
- 10. Repeat steps 4 to 7 for continuous popping.

CLEANING AND MAINTENANCE

It is strongly recommended to clean the kettle frequently to avoid burning excess oil onto the bottom of the inner pot.

After using the popcorn machine, let it cool and use a wet cloth to clean the main unit, main body and door. It is strongly recommended to wash and dry the tray after each use to avoid any bacteria buildup. The light bulb is replaceable with a 120 volt/10 watt bulb.

Any other servicing should be performed by an authorized service representative.

QUICK CLEANING PROCEDURE

Turn the switch to OFF. Pour 4 to 6 ounces (0.12–0.18 liter) of water (NO detergent is necessary) into inner pot. Switch to POP to boil the water and let the stirrer turn in order to remove excess oil stuck on the surface. After about 1 to 2 minutes of boiling, allow to cool, then pour the water into a deep bowl and discard. **CAUTION: THE KETTLE IS HOT.**

Or, remove the kettle and clean it with a Scotch-Brite® scouring pad. Do not immerse kettle or electrical plug in water.

Any trademarks or service marks of third parties herein are the trademarks or service marks of their respective owners.

©2012 Waring Consumer Products 150 Milford Road East Windsor, NJ 08520

www.waringproducts.com

Printed in China WPM SERIES IB 12WR130913

